





ASSEMBLY INSTRUCTION

TV 256



A		X1
B		X3
C		X1
D		X4
E		X4
F		X4
G		X4
H		X1
I		X20

ADULT ASSEMBLY REQUIRED