
















PART LIST







ITEM : TV450

A	B	C	D		
 <p>x1</p>	 <p>x1</p>	 <p>x1</p>	 <p>x1</p>		
E	F	G	H	I	
 <p>x1</p>	 <p>x2</p>	 <p>x2</p>	 <p>x1</p>	 <p>x1</p>	
J	K	L	M	N	O
 <p>x2</p>	 <p>x1</p>	 <p>GH-19 F</p> <p>x7</p>	 <p>GH-26 F</p> <p>x6</p>	 <p>FX-12 F</p> <p>x8</p>	 <p>GG-19 F</p> <p>x2</p>

ADULT ASSEMBLY REQUIRED

ASSEMBLY INSTRUCTION

ITEM : TV450



ADULT ASSEMBLY REQUIRED